

Fit For Work



Our natural rubber work overshoes allow you to work comfortably in the toughest conditions.

New 1300 Hi-Top design will better fit today's larger work shoe styles, including steel toe work boots.

New 2300 Hi-Top is the design and fit of the original 1300

Increased length, fuller vamp and toe box dimensions

Increased dimension of toe, ball, and heel width



New 1300



New 2300 (original 1300)



1300



2300

RUBBER OVERSHOES

HI-TOP WORK RUBBER – COVERS WORK SHOE UP TO THE ANKLE

1300	Black – Cleated Outsole	S – 3XL
------	-------------------------	---------

2300	Black – Cleated Outsole	S – 2XL
------	-------------------------	---------

10" WORK BOOT – MOLDED IN BUTTON FOR SECURE CLOSURE

1400	Black – Cleated Outsole	S – 3XL
------	-------------------------	---------

Overshoe Size	Men's
Small	6½ - 8
Medium	8 - 9½
Large	9½ - 11
X Large	11 - 12½
2X Large	12½ - 14
3X Large	14 - 15½



Additional sizing guidelines by shoe style

Ideal Applications: Food Processing, Transportation, Utilities, Construction, General Industry, Municipalities, and Agriculture.

Chemical Resistance: Acids, alcohols, bases, and diluted water solutions of most chemicals that are water soluble. Not recommended for constant contact with petroleum and oil based products.



#4040 4/14

TINGLEY
A TRADITION SINCE 1896

Distributed by:

NELSON JAMESON
INC.
800-826-8302 nelsonjameson.com

