



1. Install the wire arm into proper position (either sanitizer or foam soap)
2. Place the metal bracket into place so that the mounting holes lineup. Use these holes as well as the two holes at the top to mount the dispenser to a wall.

← FOAM SOAP POSITION →

← SANITIZER POSITION →