

How to Order Sanitary Hose Assemblies

Build Your Assembly Part Number



PSD	200	RE or SL	200 TC	200 TC	P	15/0
Hose	ID Size	Fitting Style	Size/Style First End	Size/Style Second End	Hose Sleeve Material	Assembly Length
Hose	Size Code	Coupler Style	End Style		Hose Sleeve	Assembly Length
PSD	025 = 1/4"	SL = Crimp or RE = Reusable	TC = Sanitary Clamp		S = Stainless	Feet/Inches
PSDW	037 = 3/8"	SL or RE	BS = Bevel Seat with Hex Nut		P = Polymer	
SW630	050 = 1/2"	SL or RE	BT = Bevel Male Thread			
GCR	062 = 5/8"	SL or RE	IF = Female I-Line			
SSW	075 = 3/4"	SL or RE	IM = Male I-Line			
MLT	100 = 1"	SL or RE	JP = John Perry with Hex Nut			
CSS	150 = 1-1/2"	SL or RE	JT = John Perry Male Thread			
CBT	200 = 2"	SL or RE	MT = Male Pipe Thread			
CCT	250 = 2-1/2"	SL or RE	TE = Tube End (Butt Weld)			
RSD	300 = 3"	SL = Crimp Only	DF = Cam & Groove Female			
RSDR	400 = 4"	SL	AM = Cam & Groove Male			
RSDB	600 = 6"	SL	AF = Flange			
RES		SL	QL = Q-Line			
RCR		SL				
RBT		SL				
RWS		SL				
RCT		SL				
RWD		SL				
TSC		SL				
TSB		SL				
TCB		SL				
TRS		SL				
SHF		SL				
SMD		SL				
SDB		SL				
SSD		SL				
MHH		RE = Reusable Only				
BRH		RE				
CSC		RE				
CSW		RE				
SPD		RE				
FPD		RE				
FPW		RE				

Build Your Custom Assembly in Just 7 Easy Steps.

- 1 Select code for hose style.
- 2 Specify hose ID.
- 3 Specify coupler style.
SL = crimped/permanent
RE = reusable
- 4 & 5 Specify size and style of each end fitting.
- 6 Select hose sleeve material.
- 7 Specify overall assembly length.

Need help?

We can recommend the right hose for your application!
Call our hose specialists for assistance.