

Traceable® Thermometer

Visual alarm bar
(alarm indicator)

Max memory / Hi alarm

Current reading

Min memory / Lo alarm

Memory clear
(to clear Min/Max memory)

Mode select

Mute alarm
(to mute alarm buzzer)



Traceable[®] Thermometer



Temperature metric
(°C or °F)

Alarm on/off

Sample rate

Max temperature/
Hi alarm

Min temperature/
Lo alarm

Alarm buzzer

Unit reset

Traceable® Thermometer

Integrated magnet

Integrated stand

Probe



Distributed by:

NELSON JAMESON INC.

800-826-8302 nelsonjameson.com