



Traceable® Thermohygrometer with Clock



INITIAL SETUP


- 1 Remove battery cover and insert batteries.



- 2 Once batteries are installed, press button to select setting.



- 3 The first setting, Hours, will flash on display.



- 4 Press “” and “” buttons to adjust setting.



- 5 Once finished, press button to save setting and proceed to Minutes, 12/24 Hour, etc.




- 6 Complete all settings to configure device:

- Hours
- Minutes
- 12 or 24 hour format clock
- Temperature units

- 7 Replace battery cover.



DISPLAY DETAILS



CLEARING INDIVIDUAL READINGS

1. Press select button until desired reading to be cleared is flashing.
2. Press and hold clear/revert button for 3 seconds to clear reading.

CLEARING ALL MEMORY READINGS

1. Press and hold clear/revert button for 3 seconds to clear all memory readings.

Distributed by:

NELSON JAMESON

INC.

800-826-8302 nelsonjameson.com

WARRANTY, SERVICE, OR RECALIBRATION

Traceable®

an antylla scientific company

12554 Old Galveston Rd. Suite B230

Webster, Texas 77598 USA

Ph. 281-482-1714 • Fax 281-482-9448

support@traceable.com

traceable.com

Traceable® Products are ISO 9001:2018 Quality-Certified by DNV and ISO/IEC 17025:2017 accredited as a Calibration Laboratory by A2LA.

Item No. 56000-10

Model No. 5660

©2022 1065T6_M_92-5660-00 Rev. 0 09022022

Traceable® Thermohygrometer with Clock Quick-Start Guide

