



## **Alpet D2 Quat Test for Organic Processors:**

The use of quat's can be permitted in organic processing plants as long as it has totally dissipated from the surface prior to applying food.

To test Alpet D2: Spray onto surface and allow to air dry. Apply a drop of water in 60 seconds increments to the area where Alpet D2 has evaporated. Using a test strip, rub the drop of water onto the strip (pHydrion QT-10 and QT-1000 papers are recommended or for lower concentrations the QL-110 Test Kit\*). This will show if any quat remains.

In field tests, the quat was non-detectable 30 seconds after drying. This varies depending on humidity in your location.

\*

Micro Essential Laboratory Inc PO Box 100824 | 4224 Avenue H, Brooklyn, New York 11210

ph:718.338.3618 | fax:718.692.4491

*Distributed by:*

**NELSON JAMESON**

INC.

800-826-8302 nelsonjameson.com