

ENZYFOAM + BIOREM®CD20

Curative treatment for biofilm contamination on open surfaces





Unique patented treatment combining a foaming detergent base (Enzyfoam) and a specific cocktail of enzymes (Biorem® CD20) to treat biofilms on open surfaces in the food and beverage industry. This specific treatment in combination with a sanitizing phase with an EPA approved sanitizer ensures removal of the biofilms, guaranteeing perfect hygiene for surfaces.* A preventive treatment with Biorem® Foam can be implemented to prevent biofilm recurrence.

ADVANTAGES

- **Equipment-friendly** solution, approved by Elopak
- It has been proven that Realzyme's daily enzymatic cleaning in combination with the removal of biofilms make it possible to **increase the quality of finished products and their use-by date.****
- **Positive impact on the environment** (discharge of pre-purified water)
- **Biodegradability rate (Enzyfoam)> 95%** in 28 days (OECD 302B)

FIELDS OF APPLICATION

- Treating biofilm on open surfaces

	VOLUME	REF.	CARTON	PALLET
	5L (CD20)	LIQ0020	4 bottles	24 boxes (=96 bottles)
	25L Enzyfoam	LIQ1605		24 pails
	200L Enzyfoam	LIQ1606	-	2 drums
	1000L Enzyfoam	LIQ1607	-	1 tote







* When used in normal circumstances and in accordance with the specifications for use.

** Results from the "Biofilm Expert" project carried out in partnership with Wallonia and Quality Partner.

DIRECTION OF USE

- 1 Prepare a solution of Enzyfoam, Biorem®CD20 and hot water 104 -122 °F (40-50°C) maximum.
- 2 Spread foam on surfaces with a foam dispenser
- 3 Allow to act for 30 minutes for in-depth action.
- 4 Rinse with clean water.
- 5 Carry out high strength sanitizing.
- 6 Rinse with clean water.

	Temperature	104 -122 °F (40-50°C) max.
	Action	Foaming + rinsing
	Concentration	Enzyfoam : 1% Biorem® CD20 : 0,2%
	Contact time	30 minutes (min)

Distributed by:



PH VALUE

0	1	2	3	4	5	6	7	8	9	10	11	12	13	14
---	---	---	---	---	---	---	---	---	---	----	----	----	----	----

(In solution)

CERTIFICATIONS AND REGULATIONS

- Product meets USDA regulatory sanitation performance objectives following the Food Safety and Inspection Service (FSIS) Directive 5000.1, "Verifying an Establishment's Food Safety System Handbook"
- All components of this product are listed, or excluded from listing, on the United States Environmental Protection Agency Toxic Substances Control Act (TSCA) inventory
- All components of this product are listed on Canadian DSL or NDSL or notified

SAFETY

- For professional use only.
- Consult the Safety Data Sheet and the product label for more information.

STORAGE

- Storage in the closed original packaging between 39°F and 77°F (4°C and 25°C).
- Use Biorem®CD20 within 24 months of production and 12 months after opening the product and Enzyfoam within 12 months of production and 6 months after opening the product.

